


*Origo*TM

Arc 4001i



Instruction manual



DECLARATION OF CONFORMITY

According to

The Low Voltage Directive 2006/95/EC, entering into force 16 January 2007

The EMC Directive 2004/108/EC, entering into force 20 July 2007

Type of equipment

Arc welding power source

Type designation

Arc 4001i, from serial number 833 xxx xxxx (2008 w.33)

Arc 4001i is member of the ESAB Origo™ product family

Brand name or trade mark

ESAB

Manufacturer or his authorized representative established within the EEA:

Name, address, phone, website:

ESAB AB

Lindholmsallén 9

Box 8004, 402 77 GÖTEBORG, Sweden

Phone: +46 31 509 000

Website: www.esab.com

The following harmonized standards, in force within the EEA, has been used in the design:

EN 60974-1, Arc welding equipment – Part 1: Welding power sources

EN 60974-10, Arc welding equipment – Part 10: Electromagnetic compatibility (EMC) requirements

Additional information:

Restrictive use, Class A equipment, intended for use in locations other than residential.

By signing this document, the undersigned declares as manufacturer, or the manufacturer's authorized representative established within EEA, that the equipment in question complies with the safety requirements stated above.

Date

2012-09-27

Signature

A handwritten signature in black ink, appearing to be "JF", written over a horizontal line.

Jerker Funnemark
Clarification

Position

Managing Director
Equipment & Automation

1 SAFETY	4
2 INTRODUCTION	6
2.1 Equipment	6
2.2 Control panel A22, A24	6
3 TECHNICAL DATA	7
4 INSTALLATION	8
4.1 Lifting instructions	8
4.2 Location	8
4.3 Mains supply	8
4.3.1 Recommended fuse sizes and minimum cable area	9
5 OPERATION	10
5.1 Connections and control devices	10
5.2 Turning on the power source	10
5.3 Connection of welding and return cable	11
5.4 Fan control	11
5.5 Overheating protection	11
5.6 MMA welding	11
5.7 TIG welding	11
5.8 MIG/MAG and FCAW-S welding	12
6 MAINTENANCE	12
6.1 Power source	13
6.2 Welding torch	13
7 FAULT-TRACING	14
8 ORDERING SPARE PARTS	14
DIAGRAM	16
ORDERING NUMBER	18
SPARE PARTS LIST	19
ACCESSORIES	20

1 SAFETY

Users of ESAB equipment have the ultimate responsibility for ensuring that anyone who works on or near the equipment observes all the relevant safety precautions. Safety precautions must meet the requirements that apply to this type of equipment. The following recommendations should be observed in addition to the standard regulations that apply to the workplace.

All work must be carried out by trained personnel well-acquainted with the operation of the equipment. Incorrect operation of the equipment may lead to hazardous situations which can result in injury to the operator and damage to the equipment.

1. Anyone who uses the equipment must be familiar with:
 - its operation
 - location of emergency stops
 - its function
 - relevant safety precautions
 - welding and cutting
2. The operator must ensure that:
 - no unauthorised person is stationed within the working area of the equipment when it is started up.
 - no-one is unprotected when the arc is struck
3. The workplace must:
 - be suitable for the purpose
 - be free from drafts
4. Personal safety equipment
 - Always wear recommended personal safety equipment, such as safety glasses, flame-proof clothing, safety gloves.
 - Do not wear loose-fitting items, such as scarves, bracelets, rings, etc., which could become trapped or cause burns.
5. General precautions
 - Make sure the return cable is connected securely.
 - Work on high voltage equipment **may only be carried out by a qualified electrician.**
 - Appropriate fire extinguishing equipment must be clearly marked and close at hand.
 - Lubrication and maintenance must **not** be carried out on the equipment during operation.



WARNING



Arc welding and cutting can be injurious to yourself and others. Take precautions when welding and cutting. Ask for your employer's safety practices which should be based on manufacturers' hazard data.

ELECTRIC SHOCK - Can kill

- Install and earth the unit in accordance with applicable standards.
- Do not touch live electrical parts or electrodes with bare skin, wet gloves or wet clothing.
- Insulate yourself from earth and the workpiece.
- Ensure your working stance is safe.

FUMES AND GASES - Can be dangerous to health

- Keep your head out of the fumes.
- Use ventilation, extraction at the arc, or both, to take fumes and gases away from your breathing zone and the general area.

ARC RAYS - Can injure eyes and burn skin.

- Protect your eyes and body. Use the correct welding screen and filter lens and wear protective clothing.
- Protect bystanders with suitable screens or curtains.

FIRE HAZARD

- Sparks (spatter) can cause fire. Make sure therefore that there are no inflammable materials nearby.

NOISE - Excessive noise can damage hearing

- Protect your ears. Use earmuffs or other hearing protection.
- Warn bystanders of the risk.

MALFUNCTION - Call for expert assistance in the event of malfunction.

Read and understand the instruction manual before installing or operating.

PROTECT YOURSELF AND OTHERS!




WARNING

Do not use the power source for thawing frozen pipes.



CAUTION

Read and understand the instruction manual before installing or operating.




CAUTION

This product is solely intended for arc welding.



CAUTION

Class A equipment is not intended for use in residential locations where the electrical power is provided by the public low-voltage supply system. There may be potential difficulties in ensuring electromagnetic compatibility of class A equipment in those locations, due to conducted as well as radiated disturbances.





Dispose of electronic equipment at the recycling facility!

In observance of European Directive 2002/96/EC on Waste Electrical and Electronic Equipment and its implementation in accordance with national law, electrical and/or electronic equipment that has reached the end of its life must be disposed of at a recycling facility.

As the person responsible for the equipment, it is your responsibility to obtain information on approved collection stations.

For further information contact the nearest ESAB dealer.

ESAB can provide you with all necessary welding protection and accessories.

2 INTRODUCTION

Arc 4001i is a welding power source intended for welding with coated electrodes (MMA welding) and TIG welding (Live TIG-start). Further, the power source with the control panel A24 can be used together with the wire feed unit MobilFeed. The wire feed unit uses the arc voltage as control voltage.

ESAB's accessories for the product can be found on page 20.

2.1 Equipment

The power source is supplied with:

- Instruction manual for the welding power source
- Instruction manual for the control panel in English.
Instruction manuals in other languages can be downloaded from internet www.esab.com.

2.2 Control panel A22, A24



Welding process parameters are controlled via the control panel.

See the separate instruction manual for a detailed description of the control panels.

3 TECHNICAL DATA

Arc 4001i	
Mains voltage	400 V \pm 10%, 3~ 50/60 Hz
Mains supply	S _{sc min} 2.2 MVA
Primary current	
I _{max} MMA	27 A
I _{max} TIG	20 A
I _{max} MIG/MAG	26 A
No-load power demand when in the energy-saving mode, 6.5 min. after welding	60 W
Setting range	
MMA	16 A / 21 V - 400 A / 36 V
TIG	4 A / 10 V - 400 A / 26 V
MIG/MAG	20 A / 15 V - 400 A / 34 V
Permissible load at MMA	
30 % duty cycle	400 A / 36 V
60 % duty cycle	320 A / 33 V
100% duty cycle	250 A / 30 V
Permissible load at TIG	
30 % duty cycle	400 A / 26 V
60 % duty cycle	320 A / 23 V
100% duty cycle	250 A / 20 V
Permissible load at MIG/MAG	
30 % duty cycle	400 A / 34 V
60 % duty cycle	320 A / 30 V
100% duty cycle	250 A / 27 V
Power factor at maximum current	
MMA	0.89
TIG	0.91
MIG/MAG	0.89
Efficiency at maximum current	
MMA	85 %
TIG	81 %
MIG/MAG	85 %
Open-circuit voltage without VRD function ¹⁾	91 V DC
VRD function deactivated ²⁾	58 V DC
VRD function activated ²⁾	< 35 V
Operating temperature	-10 to +40° C
Transportation temperature	-20 to +55° C
Constant sound pressure at no-load	<70 db (A)
Dimensions lxxh	652 x 249 x 423 mm
Weight	40 kg
Insulation class transformer	H
Enclosure class	IP 23
Application class	S

1) Valid for power sources without VRD specification on the rating plate.

2) Valid for power sources with VRD specification on the rating plate. The VRD function is explained in the instruction manual for the control panel.

Mains supply, S_{sc min}

Minimum short circuit power on the network in accordance with IEC 61000-3-12

Duty cycle

The duty cycle refers to the time as a percentage of a ten-minute period that you can weld or cut at a certain load without overloading. The duty cycle is valid for 40°C.

Enclosure class

The IP code indicates the enclosure class, i. e. the degree of protection against penetration by solid objects or water. Equipment marked IP23 is designed for indoor and outdoor use.


Application class

The symbol **S** indicates that the power source is designed for use in areas with increased electrical hazard.

4 INSTALLATION

The installation must be carried out by a professional.

4.1 Lifting instructions



4.2 Location

Place the power source so that its cooling air inlets and outlets are not obstructed.

4.3 Mains supply


Note

Mains supply requirements

High power equipment may, due to the primary current drawn from the mains supply, influence the power quality of the grid. Therefore connection restrictions or requirements regarding the maximum permissible mains impedance or the required minimum supply capacity at the interface point to the public grid may apply for some types of equipment (see technical data). In this case it is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment may be connected.

Make sure that the welding power source is connected to the correct supply voltage and that it is protected by the correct fuse rating. A protective earth connection must be made in accordance with regulations.

Rating plate with supply connection data



AH 0905

Note! The welding power source is designed for connection to a 400 volt system with four conductors. If the power source is to be used in countries with a higher or lower supply voltage, the power source must be connected via a safety transformer.

4.3.1 Recommended fuse sizes and minimum cable area

Arc 4001i	
Mains voltage	400V \pm 10% 3~
Mains cable area mm ²	4 G 4
Phase current I _{1eff}	16 A
Fuse	
anti-surge	20 A
type C MCB	20 A

NOTE!



Cable size and fuse rating complies to Swedish electrical regulations. Use the welding power source in accordance with the relevant national regulations.

5 OPERATION

General safety regulations for handling the equipment can be found on page 4. Read through before you start using the equipment!

5.1 Connections and control devices

- | | |
|---|---|
| 1 Mains power supply switch, 0 / 1 / Start | 4 Connection (-)
MMA: return cable or welding cable
TIG: torch
MIG/MAG: return cable |
| 2 Control panel,
see separate instruction manual | 5 Connection (+)
MMA: welding cable or return cable
TIG: return cable
MIG/MAG: welding cable |
| 3 Connection for remote control unit | |



AH 0905

5.2 Turning on the power source

Turn on the mains power by turning switch (1) to the "START" position. Release the switch, and it will return to the "1" position.

If the mains power supply should be interrupted while welding is in progress, and then be restored, the power unit will remain de-energised until the switch is again turned manually to the "START" position.

Turn the unit off by turning the switch to the "0" position.

Whether the mains power supply is interrupted or the power unit is switched off in the normal manner, welding data will be stored so that it is available next time the unit is started.

5.3 Connection of welding and return cable

The power source has two outputs, a positive terminal (+) and a negative terminal (-), for connecting welding and return cables. The output to which the welding cable is connected depends on the welding method or type of electrode used.

Connect the return cable to the other output on the power source. Secure the return cable's contact clamp to the work piece and ensure that there is good contact between the work piece and the output for the return cable on the power source.

For MMA welding, the welding cable can be connected to the positive terminal (+) or negative terminal (-) depending on the type of electrode used. The connecting polarity is stated on the electrode packaging.

5.4 Fan control

The power source has a time control that means that the fans continue to run for 6.5 minutes after welding has stopped, and the unit switches to energy-saving mode. The fans start again when welding restarts.

The fans run at reduced speed for welding currents up to 144 A, and at full speed for higher currents.

5.5 Overheating protection

The welding power source has overheating protection that operates if the temperature becomes too high. When this occurs the welding current is interrupted and a fault code is displayed on the control panel.

The overheating protection resets automatically when the temperature has fallen.

5.6 MMA welding

For MMA welding, the welding power source is supplemented with:

- welding cable with electrode clamp
- return cable with contact clamp

5.7 TIG welding


For TIG welding, the welding power source is supplemented with:

- a TIG torch with gas valve
- an argon gas tube
- an argon gas regulator
- tungsten electrode
- return cable with contact clamp

TIG welding melts the metal of the workpiece, using an arc struck from a tungsten electrode, which does not itself melt. The weld pool and the electrode are protected by shielding gas.

"Live TIG-start"

With "Live TIG start" the tungsten electrode is placed against the workpiece, when the electrode is then lifted away from the workpiece again the arc is struck at a limited current level. (12-15 A).



5.8 MIG/MAG and FCAW-S welding

For MIG/MAG welding and FCAW-S the welding power source is supplemented with:

- wire feed unit (MobileFeed)
- welding torch
- connection cable
- return cable with contact clamp

MIG/MAG welding melts a continuously supplied filler wire, with the weld pool being protected by shielding gas.

During FCAW-S welding, an arc melts a continuously supplied wire. The weld pool is protected by the powder filled cored wire.

6 MAINTENANCE

Regular maintenance is important for safe, reliable operation.

Only those persons who have appropriate electrical knowledge (authorized personnel) may remove the safety plates.



CAUTION

All guarantee undertakings from the supplier cease to apply if the customer attempts any work to rectify any faults in the product during the guarantee period.

6.1 Power source

Check regularly that the welding power source is not clogged with dirt.

How often and which cleaning methods apply depend on:


- welding process
- arc time
- placement
- surrounding environment

It is normally sufficient to blow down the power source with dry compressed air (reduced pressure) once a year.

Clogged or blocked air inlets and outlets otherwise result in overheating.

Replacing and cleaning the dust filter

- Release the dust filter according to the figure.
- Blow the filter clean with compressed air (reduced pressure).
- Ensure that the filter with the finest mesh is placed towards the grille.
- Reinstall the filter.



6.2 Welding torch

Wear parts should be cleaned and replaced at regular intervals in order to achieve trouble-free welding.

7 FAULT-TRACING

Try these recommended checks and inspections before sending for an authorized service technician.

Type of fault	Corrective action
No arc.	<ul style="list-style-type: none"> • Check that the mains power supply switch is turned on. • Check that the welding and return cables are correctly connected. • Check that the correct current value is set. • Check the mains power supply fuses.
The welding current is interrupted during welding.	<ul style="list-style-type: none"> • Check whether the thermal cut-outs have tripped (a fault code is displayed on the control panel). • Check the mains power supply fuses.
The thermal cut-out trips frequently.	<ul style="list-style-type: none"> • Check to see whether the dust filter is clogged. • Make sure that you are not exceeding the rated data for the welding power source (i.e. that the unit is not being overloaded). • Check that the welding power source is not clogged with dirt.
Poor welding performance.	<ul style="list-style-type: none"> • Check that the welding current supply and return cables are correctly connected. • Check that the correct current value is set. • Check that the correct electrodes are being used.


8 ORDERING SPARE PARTS

Repair and electrical work should be performed by an authorised ESAB service technician. Use only ESAB original spare and wear parts.

Arc 4001i is designed and tested in accordance with the international and European standards EN 60974-1 and EN 60974-10. It is the obligation of the service unit which has carried out the service or repair work to make sure that the product still conforms to the said standard.


Spare parts may be ordered through your nearest ESAB dealer, see the last page of this publication.

Diagram



Arc 4001i

Order number




Ordering no.	Denomination	Type
0460 455 880	Welding power source	Origo™ Arc 4001i, A22
0460 455 881	Welding power source	Origo™ Arc 4001i, A24
0459 839 029	Spare parts list	Arc 4001i
0460 737	Instruction manual	Control panel Origo™ A22, A24







Instruction manuals and the spare parts list are available on the Internet at **www.esab.com**




Spare parts list

Item	Qty	Ordering no.	Denomination
1	1	0458 398 002	Dust filter



Accessories

	<p>Trolley 2 wheel 0460 564 880</p>
	<p>Mounting brackets 0460 911 880</p>
	<p>Protection frame 0460 459 880</p>
	<p>Shelf for feed unit for two wheel trolley 0460 815 880</p>
	<p>Remote control unit MTA1 CAN 0459 491 880 For setting of wire feed speed, current and arc force.</p>
	<p>Remote control unit AT1 CAN 0459 491 883 For setting of current.</p>

	<p>Remote control unit AT1 CF CAN 0459 491 884</p> <p>For rough and fine setting of current.</p>
	<p>Remote control cable 10 pole - 4 pole</p> <p>5 m 0459 960 880</p> <p>10 m 0459 960 881</p> <p>25 m 0459 960 882</p>
	<p>Return cable 5 m 70 mm² 0700 006 895</p>

ESAB subsidiaries and representative offices

Europe AUSTRIA ESAB Ges.m.b.H Vienna-Liesing Tel: +43 1 888 25 11 Fax: +43 1 888 25 11 85 BELGIUM S.A. ESAB N.V. Brussels Tel: +32 2 745 11 00 Fax: +32 2 745 11 28 BULGARIA ESAB Kft Representative Office Sofia Tel/Fax: +359 2 974 42 88 THE CZECH REPUBLIC ESAB VAMBERK s.r.o. Vamberk Tel: +420 2 819 40 885 Fax: +420 2 819 40 120 DENMARK Aktieselskabet ESAB Herlev Tel: +45 36 30 01 11 Fax: +45 36 30 40 03 FINLAND ESAB Oy Helsinki Tel: +358 9 547 761 Fax: +358 9 547 77 71 FRANCE ESAB France S.A. Cergy Pontoise Tel: +33 1 30 75 55 00 Fax: +33 1 30 75 55 24 GERMANY ESAB GmbH Solingen Tel: +49 212 298 0 Fax: +49 212 298 218 GREAT BRITAIN ESAB Group (UK) Ltd Waltham Cross Tel: +44 1992 76 85 15 Fax: +44 1992 71 58 03 ESAB Automation Ltd Andover Tel: +44 1264 33 22 33 Fax: +44 1264 33 20 74 HUNGARY ESAB Kft Budapest Tel: +36 1 20 44 182 Fax: +36 1 20 44 186 ITALY ESAB Saldatura S.p.A. Bareggio (Mi) Tel: +39 02 97 96 8.1 Fax: +39 02 97 96 87 01 THE NETHERLANDS ESAB Nederland B.V. Amersfoort Tel: +31 33 422 35 55 Fax: +31 33 422 35 44	NORWAY AS ESAB Larvik Tel: +47 33 12 10 00 Fax: +47 33 11 52 03 POLAND ESAB Sp. z o.o. Katowice Tel: +48 32 351 11 00 Fax: +48 32 351 11 20 PORTUGAL ESAB Lda Lisbon Tel: +351 8 310 960 Fax: +351 1 859 1277 ROMANIA ESAB Romania Trading SRL Bucharest Tel: +40 316 900 600 Fax: +40 316 900 601 RUSSIA LLC ESAB Moscow Tel: +7 (495) 663 20 08 Fax: +7 (495) 663 20 09 SLOVAKIA ESAB Slovakia s.r.o. Bratislava Tel: +421 7 44 88 24 26 Fax: +421 7 44 88 87 41 SPAIN ESAB Ibérica S.A. Alcalá de Henares (MADRID) Tel: +34 91 878 3600 Fax: +34 91 802 3461 SWEDEN ESAB Sverige AB Gothenburg Tel: +46 31 50 95 00 Fax: +46 31 50 92 22 ESAB international AB Gothenburg Tel: +46 31 50 90 00 Fax: +46 31 50 93 60 SWITZERLAND ESAB AG Dietikon Tel: +41 1 741 25 25 Fax: +41 1 740 30 55 UKRAINE ESAB Ukraine LLC Kiev Tel: +38 (044) 501 23 24 Fax: +38 (044) 575 21 88	North and South America ARGENTINA CONARCO Buenos Aires Tel: +54 11 4 753 4039 Fax: +54 11 4 753 6313 BRAZIL ESAB S.A. Contagem-MG Tel: +55 31 2191 4333 Fax: +55 31 2191 4440 CANADA ESAB Group Canada Inc. Mississauga, Ontario Tel: +1 905 670 02 20 Fax: +1 905 670 48 79 MEXICO ESAB Mexico S.A. Monterrey Tel: +52 8 350 5959 Fax: +52 8 350 7554 USA ESAB Welding & Cutting Products Florence, SC Tel: +1 843 669 44 11 Fax: +1 843 664 57 48 Asia/Pacific AUSTRALIA ESAB South Pacific Archerfield BC QLD 4108 Tel: +61 1300 372 228 Fax: +61 7 3711 2328 CHINA Shanghai ESAB A/P Shanghai Tel: +86 21 2326 3000 Fax: +86 21 6566 6622 INDIA ESAB India Ltd Calcutta Tel: +91 33 478 45 17 Fax: +91 33 468 18 80 INDONESIA P.T. ESABindo Pratama Jakarta Tel: +62 21 460 0188 Fax: +62 21 461 2929 JAPAN ESAB Japan Tokyo Tel: +81 45 670 7073 Fax: +81 45 670 7001 MALAYSIA ESAB (Malaysia) Snd Bhd USJ Tel: +603 8023 7835 Fax: +603 8023 0225 SINGAPORE ESAB Asia/Pacific Pte Ltd Singapore Tel: +65 6861 43 22 Fax: +65 6861 31 95	SOUTH KOREA ESAB SeAH Corporation Kyungnam Tel: +82 55 269 8170 Fax: +82 55 289 8864 UNITED ARAB EMIRATES ESAB Middle East FZE Dubai Tel: +971 4 887 21 11 Fax: +971 4 887 22 63 Africa EGYPT ESAB Egypt Dokki-Cairo Tel: +20 2 390 96 69 Fax: +20 2 393 32 13 SOUTH AFRICA ESAB Africa Welding & Cutting Ltd Durbanville 7570 - Cape Town Tel: +27 (0)21 975 8924 Distributors <i>For addresses and phone numbers to our distributors in other countries, please visit our home page</i> www.esab.com
---	--	--	--



www.esab.com

